AutoFlex CONNECT II

1. Mount either of the Extension Enclosures beside the AutoFlex control. Mount the other enclosure beside the Expansion Box.
2. Connect the cable with the large strain reliefs to one of the enclosures. Route the cable and then connect it to the other enclosure.



Extension Enclosures

Expansion Box 14



or



3. Connect the Extension Cable to the Communication Controller on the inside cover of the control

Communication Controller

4. Connect the extension cable to the connector in the Expansion Box.

Expansion Box 6